



**Customer Service:
1.800.626.5651**

Magnetic mounting plates optional
See page 29.



Series 96H2 Articulator

Adjustments:

0°-30° Progressive Side Shift

Protrusive: 0°-75°

Comes complete with:

Adjustable incisal guide, standard incisal pin, extension pin, orbitale indicator, 10 disposable mounting plates, instruction manual, carrying case

Item: 003302-000

96H2 Series Accessories



Plastering Stand 96-0

For convenient stabilization of the articulator in an inverted position during the mounting of the mandibular cast.

Item: 003368-000



Adjustable Incisal Guide

May be moved anteriorly or posteriorly which minimizes having to adjust for the "x" dimension. Incline may be adjusted and locked from 0° to 40° protrusive. Adjustable lateral wings establish the degree of incisal freedom from 0° to 45°.

Item: 009551-000



Standard Incisal Pin

Item: 003330-000

Incisal Pin Extension for the H2

Item: 005243-000



Orbitale Indicator (Frankfort Horizontal Plane)

Used with procedures employing the infra-orbital notch as an anatomical third reference point during facebow application and transfer.

Item: 010046-000